

User Manual E.006


Exx-0603n Series Digital Controllers

Release: 2.4


Date: 2024-08-30

This document is valid for the following products:

- **EOD-060310**
Digital Controller, 1 Channel, OEM-Board, SGS
- **EOC-060310**
Digital Controller, 1 Channel, OEM-Board, Cap. Sensor
- **EBD-060310**
Digital Controller, 1 Channel, SGS
- **EBC-060310**
Digital Controller, 1 Channel, Cap. Sensor
- **EBD-060320**
Digital Controller, 2 Channels
- **EBD-060325**
Digital Controller, 2 Channels plus 1 constant voltage
- **EBD-060330**
Digital Controller, 3 Channels



EBD-060310/EBC-060310



EBD-060320, EBD-060325 (2 Status-LEDs) and
EBD-060330 (3 Status-LEDs)

All rights related to this document are reserved.
Copying and quoting of the manual or parts of it is
prohibited and allowed only after written permission
of nanoFaktur GmbH.

This manual is for information only and subject to
change without notice. Images may not be up to
date.


Contents

1.	Declaration of Conformity	4
2.	ExD-0603n Digital Controllers	6
2.1.	Specification	6
2.2.	Dimensions EOx-060310	7
2.3.	Dimensions EBx-060310/310	8
2.4.	Dimensions EBD-060320, EBD-060325, EBD060330	9
3.	Interfaces.....	10
3.1.	EBx-060310, EOx-060310, Front	10
3.2.	EBD-060320, EBD-060325, EBD-060330, Front	11
3.3.	Pin-Assignments.....	12
3.3.1.	Analog I/O of EBD-060320, EBD-060325 and EBD-060330	12
3.3.2.	DSub15f and DSub25f, Stage-Connectors	13
4.	Software and Communication.....	14
4.1.	Software Installation	14
4.1.1.	Download up-to-date software and documentation	14
4.1.2.	Install Windows® driver for USB (as COM-port)	14
4.1.3.	Setup TCP/IP for Ethernet	15
4.2.	Operation and Tuning via the nFControl GUI	16
4.2.1.	Install nFControl GUI	16
4.2.2.	Quick guide.....	16
4.3.	Commanding.....	21
4.3.1.	Package format.....	21
4.3.2.	Command-Set.....	23
4.3.3.	Parameters	26
4.4.	Operation	29
4.4.1.	Position Commanding and Reading	29
4.4.2.	Function block diagram	29
4.4.3.	Target selection.....	30
4.4.4.	Trajectory controlling	31
4.4.5.	Analog I/O	32
4.4.6.	Event.....	33
4.4.7.	Data-Recorder	34

4.4.8.	Firmware update	36
4.4.9.	Macro function	37
4.4.10.	Auto-zero function	41
5.	Explanation: Open- and Closed-Loop	42
5.1.	Open Loop Behavior	42
5.2.	Voltage-Behavior of a d_{33} - PZT	43
5.3.	Closed Loop Operation	44
6.	Troubleshooting	45

1. Declaration of Conformity

according to ISO / IEC Guide 22 and EN 45014

Manufacturer:	nanoFaktur GmbH	
Address of Manufacturer:	Peterzeller Str. 8c 78048 Villingen-Schwenningen Germany	

The manufacturer declares that the product

Short Description:	Digital Controller, Voltage-Amplifier
Model Numbers:	EBC-060310, EBD-060310, EBD-060320, EBD-060325, EBD-060330, EOC-060310, EOD-060310
Product Options:	EBD/EBC, Standard EOD/EOC, with appropriate additional enclosure only, not in the scope of delivery

is consistent with the following standards and directives:

2014/35/EU, Low Voltage Directive (LVD)

2014/30/EU, EMC Directive

2011/65/EU/ RoHS Directive

Safety (Low Voltage Directive): IEC 61010-1:2010, IEC 61010-1:2010/AMD1:2016

EMC: EN 61326-1:2013

RoHS: EN IEC 63000:2018


Electrical equipment which is intended to be integrated in other electrical equipment or enclosures, only conforms to the cited EMC Standards and normative documents, if the user ensures compliant enclosures and connections when integrating. Appropriate measures: installation of the components in qualified shielded enclosures and the usage of qualified connectors.

Villingen-Schwenningen, Germany, February, 2024

Dipl.-Ing. (FH) Klaus Pollak, Director

Caution! High Voltage!

Must be read!



The devices described in this manual are high-voltage amplifiers. Improper handling may harm the health of the operator or even be lethal.

Operating personnel must have basic understanding of voltage-amplifying electronics and piezo-electricity. Persons handling open (OEM, bare boards) electronics must be entitled to handle high-voltage electronics according to the valid rules. Safety cannot be guaranteed if the devices are operated incorrectly.


Warranty and liability of nanoFaktur are void if housed devices are opened or in case of any other hardware-manipulations. Use the determined interfaces for connections only. Intentional or default improper operation void all warranty of liability.

2.ExD-0603n Digital Controllers


2.1. Specification

Products	Digital Controllers for Piezo-Actuators/Displacement-Sensors		
Product Numbers	Exx-0603n (n=number of channels times 10)	Unit	Tolerance
Channels	1-3		
Output Voltage for Piezo	-45 to +180	V	max.
Current	150	mA	peak max.
Average Current	60	mA	max.
Sensors	ExD-versions, Strain-Gages (SGS) ExC-versions, capacitive sensors		
Resolution	18	Bit	
Control Loop Time	20 for ExD-060310/ExC-060310 40 for 2-3 channel controllers	µs µs	
Control Parameters	PID, 2 Notch Filters per channel		
Software	nFControl Windows™ GUI		
Operating System Requirements	Microsoft® Windows™ 7/8/10		
Wave-Generators	Sine-wave only		
Data-Recorders	2 Recorders (each has 512 data)		
Digital Interfaces	USB 2.0 as COM-port, Ethernet, RS232 (optional)		
Analog Input	settable, -10 to +10, -5 to +5, 0 to 10 (Internal 1k Low pass filter)	V	
Analog Output	-5 to + 5 (for EBD-0602xx) -5 to +10 (for EBD-0603xx)	V	
Connection, Analog I/O	2x BNC (1 CH), DSub15f (2, 3 CH Versions)		
Connection, Piezo and Sensor	DSub15f (1 CH), DSub25f (2, 3 CH Versions)		
Connection, P/S	SwitchCraft RASPC10PS		
P/S, counter-socket	SwitchCraft PowerJack S10KS12		
Power Supply (Vin)	external		
Vin Voltage	24 (1.5A min.)	VDC	
Vin Protection	Power input reverse polarity protection		
Static Power Consumption	Ca. 7.5	W	
Ambient Temperature	+10 to +40	°C	
Standards (EOD/EOC with appropriate additional enclosure only, not in the scope of delivery)	2014/35/EU, Low Voltage Directive (LVD) 2014/30/EU, EMC Directive 2011/65/EU/ RoHS Directive Safety (Low Voltage Directive): IEC 61010-1:2010, IEC 61010-1:2010/AMD1:2016 EMC: EN 61326-1:2013 RoHS: EN IEC 63000:2018		


2.2. Dimensions EOx-060310



2.3. Dimensions EBx-060310/310




2.4. Dimensions EBD-060320, EBD-060325, EBD060330



3. Interfaces

3.1. EBx-060310, EOx-060310, Front



A: Switch, **green**: normal status, **red**: no stage connected, etc.

B: SwitchCraft RASPC10PS, Power Supply, 24 VDC 1.5A

C: Mini USB-B, Communication (as COM-port)

D: RJ45, Ethernet, Communication, optional

E: BNC (bottom), Analog-Input, 0..+10 V (-10..+10 V, -5..+5 V settable at works)


F: BNC (top), Analog-Output, analogue -5..+5 V

G: DSub15f, Connection for assigned piezo-actuator/position-sensor

H: LED, Servo-Status, **green**: on-target, **yellow**: overflow, off: servo-off

I: Trigger input/output (optional for EOD)

3.2. EBD-060320, EBD-060325, EBD-060330, Front



A: Switch, **green**: normal status, **red**: no stage connected, etc.

B: SwitchCraft RASPC10PS, Power Supply, 24 VDC 1.5A

C: Mini USB-B, Communication (as COM-port)

D: RJ45, Ethernet, Communication

E: DSub15, Analogue-I/O

F: DSub25f, Connection for assigned piezo-actuators/position-sensors

G: 2x(3x) LED, Servo-Status, **green**: on-target, **yellow**: overflow, off: servo-off

3.3. Pin-Assignments

3.3.1. Analog I/O of EBD-060320, EBD-060325 and EBD-060330

DSub15f (VGA-kind, 9-pin housing)

No.	Name	Direction	Function
1	AIN3	Input	3rd Analog input, for EBD-060330 only
2	GND	-	Ground
3	AIN2	Input	2nd Analog input
4	GND	-	Ground
5	AIN1	Input	1st Analog input
6	OUT3	Output	3rd Monitor output, for EBD-060330 only
7	GND	-	Ground
8	OUT2	Output	2nd Monitor output
9	GND	-	Ground
10	OUT1	Output	1st Monitor output
11	R	-	Reserved
12	R	-	Reserved
13	NC	-	Not connected
14	GND	-	Ground
15	GND	-	Ground

3.3.2. DSub15f and DSub25f, Stage-Connectors

EBD 1 channel versions are equipped with DSub15 stage-connectors, while 2- and 3-channel versions have DSub25.

DSUB15	DSUB25	Name	Function
8	13	RSV1	Reserved signal
15	25	ID-Chip	ID-Chip signal
7	12	RSV2	Reserved signal
14	24	RSV3	Reserved signal
6	11	Vp	Positive power supply
13	23	GND	Ground
5	10	Vn	Negative power supply
12	22	Vref+	Voltage reference positive
4	9	Vs1-	Ch1 Sensor signal negative
11	21	Vref-	Voltage reference negative
3	8	Vs1+	Ch1 Sensor signal positive
10	20	GND	Ground
2	7	NC	No connection
9	19	Hv1-	Ch1 Piezo driving signal negative
1	6	Hv1+	Ch1 Piezo driving signal positive
-	5	Vs2+	Ch2 Sensor signal positive
-	18	Vs2-	Ch2 Sensor signal negative
-	4	Vs3+	Ch3 Sensor signal positive
-	17	Vs3-	Ch3 Sensor signal negative
-	2	Hv2+	Ch2 Piezo driving signal positive
-	3	Hv2-	Ch2 Piezo driving signal negative
-	16	Hv3+	Ch3 Piezo driving signal positive
-	15	Hv3-	Ch3 Piezo driving signal negative
-	14	NC	No connection
-	1	NC	No connection

4. Software and Communication

4.1. Software Installation

4.1.1. Download up-to-date software and documentation

<https://www.nanofaktur.com/support>

EBD-xxx2xx Software Support.zip


Password: nFSoftw

The following chapter describes how a USB-port is configured as an COM port. The chapter after this is describing how to configure the Ethernet-interface as TCP/IP port.

4.1.2. Install Windows® driver for USB (as COM-port)

When the EBD-0603x0/3x0 USB is connected to PC (ca. 2 seconds after controller has been switched on), Windows shows a new device: USB to COM port:


Please download the windows driver from FTDI (as shown below)



The screenshot shows the FTDI website's 'Virtual COM Port Drivers' page. The page includes a navigation menu on the left with links for Home, Products, Drivers, Firmware, Support, and more. The main content area features a section for 'Virtual COM Port Drivers' with a sub-section for 'VCP Drivers'. Below this, there is a table titled 'Currently Supported VCP Drivers' which lists supported operating systems and processor architectures.

Operating System	Release Date	Processor Architecture						
		x86 (32-bit)	x64 (64-bit)	PPC	ARM	MIPSII	MIPSIV	SH4
Windows*	2017-08-30	2.12.28	2.12.28	-	-	-	-	-

After installing the driver, the device-manager shows a new COM-port device:



The controller can be now connected via the nFControl.exe (as RS232).

4.1.3. Setup TCP/IP for Ethernet

For Ethernet connection, the controller's IP address can be set to be static or DHCP.

A static IP-address is commonly used when connecting a controller to a PC directly. DHCP should be used when a controller is in a network.

Use parameter 0xFF010001 to select method to use (0=static, 1=DHCP)

When controller is configured to be static (default), setup controller's IP address with parameter 0xFF010012. And the PC side should also be setup in the same subnet class.

Note: It is recommended to use USB/RS232 interface to modify the Ethernet settings.

4.2. Operation and Tuning via the nFControl GUI

nanoFaktur GmbH provides a GUI for Windows®: nFControl.exe. This is convenient for the first usage and tuning of controllers. Interface functions are realized in the nF_interface.dll. It can be used for Labview or Python(32bits) programming.


Demo source code (written in C and can be compiled with MinGW-32bits) is also provided.

4.2.1. Install nFControl GUI

At first, there is no setup.exe for this demo software. Just un-zip all the files into a local folder.

4.2.2. Quick guide

- 1) connect to controller (or simulation) with top-menu **'Interface'**




Note1: The USB interface is considered as an COM port.

Note2:

Some command needs "Command-level 1". nFControl.exe sends "0xFF0 1" at interface 'connect'. It is recommended to take the same step by customer's Software or controller-Macro.

- 2) test commands with '**Main -> Command Terminal**'
send "?0xffb" to show controller information,
send "?0xffff" to show all valid commands,
etc.



3) view and/or modify parameter-values with 'Main -> Parameters'

Parameters								
Parameter group: Movement		Action: Flash to File		Run				
Description	Channel	Parameter-ID	Level	DataType	Operation	RAM-value	Flash-value	Factory-default
Axis name	1	0x20000001	Advan...	String	Writable	X	X	X
Axis unit	1	0x20000002	Advan...	String	Writable	um	um	um
Trajectory controlling	1	0x20400000	Advan...	Integer	Writable	0	0	0
Maximal acceleration(un...	1	0x20400001	Advan...	Float	Writable	0,0100	0,0100	0,0100
Maximal velocity (unit/s)	1	0x20400002	Advan...	Float	Writable	0,1000	0,1000	0,1000
On-target tolerance	1	0x20400010	Advan...	Float	Writable	0,1000	0,1000	0,1000
On-target setup timing (s)	1	0x20400011	Advan...	Float	Writable	0,0100	0,0100	0,0100
Close-loop soft-high-limit	1	0x20400020	Advan...	Float	Writable	100,0000	100,0000	100,0000
Close-loop soft-low-limit	1	0x20400021	Advan...	Float	Writable	0,0000	0,0000	0,0000
Open-loop soft-high-limit	1	0x20400022	Advan...	Float	Writable	180,0000	180,0000	180,0000
Open-loop soft-low-limit	1	0x20400023	Advan...	Float	Writable	-45,0000	-45,0000	-45,0000
Close-loop hard-high-limit	1	0x20400030	Service	Float	Read-on...	1100,0000	-	1000,0000
Close-loop hard-low-limit	1	0x20400031	Service	Float	Read-on...	-1100,0000	-	-1000,0000
Open-loop hard-high-limit	1	0x20400032	Service	Float	Read-on...	180,0000	-	180,0000
Open-loop hard-low-limit	1	0x20400033	Service	Float	Read-on...	-45,0000	-	-45,0000
Close-loop P-term	1	0x20400100	Advan...	Float	Writable...	0,1000	0,1000	0,0010
Close-loop I-term	1	0x20400101	Advan...	Float	Writable...	10,0000	10,0000	0,0000
Close-loop D-term	1	0x20400102	Advan...	Float	Writable...	0,0000	0,0000	0,0000


For parameters with 'Writable' property, double click to change the value.

RAM-value is lost when controller is rebooted or powered off.


The flash-values are used when the controller gets restarted.

4) PID tuning


Configure the recording length by the “Movement and Monitoring” -> “Recorder time (ms)” .
 This value can be set to 100 ~ 500ms.




In open loop mode, click ‘**Check**’ to see the step response (depends on stage, the FFT varies).



Enable Notch-filter (as shown 1210Hz) and check again



Then turn '**Servo**' to on.



In order to avoid oscillations during the PID parameter tuning, first set P-Term to a small value e.g. 0.01,

Click the '**Check**' button to see the step response during parameter tuning.

Recommended values:

P-Term: starts from 0.01, step 0.01

I-Term: starts from 10.0, step 1.0 ~ 100.0

D-Term: 0.0 (valid from firmware rev.4.20)

Read the Wiki example

https://en.wikipedia.org/wiki/PID_controller#/media/File:PID_Compensation_Animated.gif for deeper understanding.

4.3. Commanding

ExD-060xxx uses a binary command set. Data should be sent in Little-Endian format, i.e: Byte0 - Byte1 - Byte2 -...

For double-word, the lowest address (byte0) should be sent first.

Note: In case of interrupted communication, controllers wait 2-seconds for the rest package. After that an interface-timeout-error is set and the incomplete package will be removed.

4.3.1. Package format

Below shows the package definition, please see nF_common.h in the software package for details:

```

TYPEDEF STRUCT __ATTRIBUTE__((PACKED)) _CMD_PACKAGE_ {
  u16   len;           // total package length in bytes
  u16   CmdId;        // command ID
  u16   CustomId;     // value will be just returned (can be used to diff routine)
  u8    opt;          // option: e.g. slave should acknowledge, CRC or check-sum, etc.
  u8    seq;          // sequence number (set by controller for response)
  u8    IntfId;       // interface ID: set by controller
  u8    ChkSumHeader; // check-sum for the header (when no command data, package ends here)
  u8    *pParam;      // command data, variable length (not included in package when length is 0)
  u8    ChkSumData;   // check-sum for command data (not included in package when data length
is 0)
}CMD_PACKAGE;
  
```

Package to controller:

Byte1/2	Byte3/4	Byte5/6	Byte7	Byte8	Byte9	Byte10	Byte11...	LastByte
Len	CmdId	CustomId	opt	0	0	Sum	Command-Data	SumData

For Command-Data:

Byte1	Byte2~N	Byte N+1	ByteN+2... ..
Data format A	DataA	Data format B	Data B ...

As an example, the 'pop controller's error' should be sent without data:

len = 0x000A (=10Bytes, from item len to ChkSumHeader)

CmdId = 0x1000

CustomId = 0x0000 (any value for host software only)

Opt = 0x00 (for reading)

Seq = 0x00 (not used by controller)

IntfId = 0x00 (not used by controller)

ChkSumHeader = 0xE5 (Package check sum should be 0xFF)

=> Data to controller: 0x0A - 0x00 - 0x00 - 0x10 - 0x00 - 0x00 - 0x00 - 0x00 - 0x00 - 0xE5

For package with data, data format should also be sent. For example: 'Set target'

len = 0x0012 (18 bytes)

CmdId = 0x2004 (Open-loop target)

CustomId = 0x0000

Opt = 0x21 (for writing and requires-acknowledge)

Seq = 0x00
 Infid = 0x00
 ChkSumHeader = 0xA8
 Format1 = 0x00 (U8)
 Data1 = 0x00 (index of the first axis)
 Format2 = 0x02 (Float)
 Data2 = 10.55
 ChkSumData = 0xFF - sum(from Format1 to Data2)

=> Data to controller: 0x12 0x00 0x04 0x20

Package from controller:

The response package from controller has same definition. Below shows part of the controller's response (command 0xFFFF: show system information)

```
dd 01 fb ff 00 00 10 00 00 17 04 4d 61 6e 75 66
61 63 74 75 72 65 72 3a 00 04 6e 61 6e 6f 46 41
4b 54 55 52 20 47 6d 62 48 00 0a 04 44 65 76 69
63 65 20 4e 61 6d 65 3a 00 04 45 42 44 2d 31 32
30 32 78 30 00 0a 04 44 65 76 69 63 65 20 53 4e
3a 00 04 31 32 33 34 35 36 37 38 00 0a 04 42 6f
<...>
```

This first 10 Bytes is the header. Then follows <format><data><format><data>...

In the above package:

```
<format:04=string> <data: string-end with NULL> <... repeat>
<format: 0a=Linefeed, no data>
<format:04=string> <data: string-end with NULL>
```

So the response can be shown as:

```
Manufacturer: nanoFAKTUR GmbH <Linefeed>
Device Name: <...>
```

Please see the software header file for details.

In the nF_interface.dll, there are functions like nF_intf_write_command() and nF_intf_read_command() for simplifying the procedure. There are also some 'top-level' functions such as nF_set_dev_axis_target().

C-source code is also provided for demo purposes.

4.3.2. Command-Set

Note:

- “[]” means optional parameters
- “{ }” means one or more parameters
- “- ” command operation invalid

Command - ID	Parameters for reading	Parameters for writing	Level	Description
System				
0xFFFF	[[<CommandID>]]	-	0	show information of commands
0xFFFE	[[<ParameterID>]]	-	0	show information of parameters
0xFFFD	[[<ErrorCode>]]	-	0	show information of errors
0xFFFB		-	0	show information of system
0xFFFA		-	0	show information of interface
0xFFF9	[[<ID>]]	-	0	show list of command/parameter options
0xFFF1	-	<Parameter>	1	See Firmware update
0xFFF0	[[<Level>]]	<CommandLevel> [password]]	0	command level set/get (No password for level 0 and 1)
0xFF00	-		0	system reset
Macro				
0xE013	-	<index>	0	Macro wait event (index: event-id)
0xE012	-	<millisecond>	0	Delay inside macro function
0xE011	-		0	Stop running macros
0xE010		<string>[<times>]	0	Show running status / Start macro
0xE007			0	Show macro memory status / memory defragmentation
0xE006	-	<string>	0	Delete macro
0xE005		<string>	0	Default macro set/get
0xE004	<string>	-	0	Show macro content
0xE003		-	0	List all macros
0xE002	-		0	End of recording macro
0xE000	-	<string>	0	start recording macro
Event				
0xD042	[[<index>]]	<index><set/clear>	0	event status set/get
0xD041	[[<index>]]	<index><enable/disable>	0	event enable set/get
0xD040	[[<index>]]	<index><mode><source>	0	event configuration set/get
ID-Chip				
0xD0FF		-	1	IDChip status
0xD000			1	IDChip parameters store / restore
Parameter R/W				
0x6005	[[<index><parameterID>]]	-	0	get factory-default parameters
0x6004	-	<option>	0	restore flash to volatile parameters
0x6003	-	<option>	0	save volatile parameters to flash
0x6002	[[<index><parameterID>]]	<index><parameterID><data>	0	non-volatile parameters set/get
0x6001	[[<index><parameterID>]]	<index><parameterID><data>	0	volatile parameters set/get

Command - ID	Parameters for reading	Parameters for writing	Level	Description
Data Recorder				
0x4051	[[<index>]]	{<index><eventID>}	0	recorder event selection set/get
0x4050	[[<uint>]]	{<index><mode><source>}	0	recorder source configuration set/get
0x4042	[[<index>]]	-	0	get recorded data-length
0x4041	[[<index>]]	{<index><rate>}	0	recorder rate set/get
0x4040	[[<index>]]	{<index><enable/disable>}	0	recorder enable set/get
0x4011	<index><from><length> [format]	-	0	get recorder table data
0x4000	-	[[<index>]]	0	clear recorder table
Piezo-high-voltage (HV)				
0x22FE	[[<index>]]	{<index><enable/disable>}	1	HV-output-enable set/get
0x22FD	[[<index>]]	-	0	get HV interlock status
0x2214	[[<index>]]	-	0	get HV setting
0x2212	[[<index>]]	-	0	get HV temperature
0x2210	[[<index>]]	-	0	get DAC value
Sensor				
0x21FE	[[<index>]]	{<index><source>}	1	Monitor ADC selection set/get
0x21FD	[[<index>]]	{<index><mode>}	1	Analog I/O configuration set/get
0x2150	-	[[<index>]]	1	Sensor offset auto-adjustment
0x2114	[[<index>]]	-	0	get analog-in voltage
0x2113	[[<index>]]	-	0	get analog-in ADC
0x2112	[[<index>]]	-	0	get filtered sensor value
0x2111	[[<index>]]	-	0	get sensor value
0x2110	[[<index>]]	-	0	get sensor ADC
Motion				
0x20FF	[[<index>]]	-	0	Show information of axes
0x2050	[[<index>]]	{<index><velocity>}	0	Velocity set/get
0x204F			0	Stage status
0x2044	[[<index>]]	{<index><mode>}	0	Event controlled motion
0x2043	-	[[<index>]]	0	Stop motion
0x2042	[[<index>]]	{<index><enable/disable>}	0	Trajectory controlling set/get
0x2041	[[<index>]]	{<index><source>}	0	target source selection set/get
0x2040	[[<index>]]	{<index><enable/disable>}	0	servo controlling set/get
0x2015	[[<index>]]	-	0	get currently controlling target
0x2014	[[<index>]]	-	0	get currently controlling voltage
0x2013	[[<index>]]	-	0	get currently position error
0x2012	[[<index>]]	-	0	get currently target
0x2011	[[<index>]]	-	0	get overflow status
0x2010	[[<index>]]	-	0	get on-target status
0x2005	-	{<index><target>}	0	set open-loop target relative
0x2004	[[<index>]]	{<index><target>}	0	open-loop target set/get
0x2003	-	{<index><target>}	0	set close-loop target relative

Command - ID	Parameters for reading	Parameters for writing	Level	Description
0x2002	[[<index>]]	{<index><target>}	0	close-loop target set/get
0x2001	[[<index>]]	-	0	get position
Controller status				
0x1000		-	0	Get (and reset) error-code of controller

Note: Depending on the firmware version, the command set may vary.

Please use the command “? 0xFFFF” to see all valid commands.

For example, the description for command “pop controller’s error” is:

“4096[0x1000] 1[0x00000001] 255[0x000000ff] Pop controller's error “

4096[0x1000]: command ID, Decimal and hexadecimal

1[0x00000001]: options for reading

255[0x000000ff]: options for writing

Byte	Value	Description of options
0	01	Syntax: (please see Parameters for writing in the table above) 0xFF = Operation not valid (i.e., command not for writing) 0x01 = No parameters
1	00	Command level: 0 = Normal 1 = Advanced Others = reserved
2	00	Reserved
3	00	Reserved

4.3.3. Parameters

Parameter-ID	Data format	Read-only	Level	Description
System				
0xFF010100	unsigned int	Y	0	RS232 Baud-rate
0xFF010014	string		1	Network gate-way to set
0xFF010013	string		1	Network netmask to set
0xFF010012	string		1	IPv4 address to set
0xFF010004	string	Y	0	Network gate-way readback
0xFF010003	string	Y	0	Network netmask readback
0xFF010002	string	Y	0	IPv4 address readback
0xFF010001	int		1	IPv4 address assignment (static=0/DHCP=1)
0xFF010000	string	Y	0	MAC address
0xFF000021	string	Y	0	Board name
0xFF000020	string	Y	0	Board setup
0xFF000013	unsigned int		1	Device ID
0xFF000012	string	Y	0	Device name
0xFF000011	string	Y	0	Device serial-number
0xFF00000F	float	Y	0	Control-loop time(s)
0xFF000005	unsigned int	Y	0	Number of wave-generators
0xFF000004	unsigned int	Y	0	Number of recorders
0xFF000003	unsigned int	Y	0	Number of piezo-channels
0xFF000002	unsigned int	Y	0	Number of sensor-channels
0xFF000001	unsigned int	Y	0	Number of axes
Filter				
0xC0400904	float		1	User IIR-filter: A2
0xC0400903	float		1	User IIR-filter: A1
0xC0400902	float		1	User IIR-filter: B2
0xC0400901	float		1	User IIR-filter: B1
0xC0400900	float		1	User IIR-filter: B0
0xC0400821	float		0	Notch2 bandwidth (%)
0xC0400820	float		0	Notch2 -3dB frequency (0.0 = disabled)
0xC0400801	float		0	Notch1 bandwidth (%)
0xC0400800	float		0	Notch1 -3dB frequency (0.0 = disabled)
0xC0400101	float		0	IIR-LPF Quality factor
0xC0400100	float		0	IIR-LPF -3dB frequency
0xC0400000	unsigned int		0	low-pass-filter (LPF) types use "?0xFFF9 0xC0400000" to see valid settings
Data recorder				
0x40400000	unsigned int		0	recorder rate
Motion				
0x21400201	float		1	Analog input gain
0x21400200	float		1	Analog input offset
0x20400102	float		1	close-loop D-term

Parameter-ID	Data format	Read-only	Level	Description
0x20400101	float		1	close-loop I-term
0x20400100	float		1	close-loop P-term
0x20400033	float	Y	0	open-loop hard-low-limit
0x20400032	float	Y	0	open-loop hard-high-limit
0x20400031	float	Y	0	close-loop hard-low-limit
0x20400030	float	Y	0	close-loop hard-high-limit
0x20400023	float		1	open-loop soft-low-limit
0x20400022	float		1	open-loop soft-high-limit
0x20400021	float		1	close-loop soft-low-limit
0x20400020	float		1	close-loop soft-high-limit
0x20400011	float (seconds)		1	on-target setup timing
0x20400010	float		1	on-target tolerance
0x20400002	float		1	maximal velocity (unit/s)
0x20400001	float		1	maximal acceleration (unit/s^2)
0x20400000	int		1	Trajectory controlling (OFF=0 / ON=1)
0x20000002	string		1	axis unit
0x20000001	string		1	axis name
IDChip parameters				
0x21000005	string	Y	0	Stage serial number
0x21000004	string	Y	0	Stage production date
0x21000003	string	Y	0	Stage type
0x21000002	int	Y	0	Stage configuration
0x21000001	string	Y	0	Stage manufacture

Note: Depends on firmware version, the parameter-list may vary. Please use command “? 0xFFFE” to see a detailed description of valid parameters.

For example, the description for parameter “Stage serial number” is:

“553648132[0x21000004] 2097153[0x00200001] 4[0x00000004] 260[0x00000104] Stage serial number “

553648132[0x21000004]: parameter ID, Decimal and hexadecimal

2097153[0x00200001]:

0x0020 (the high 16bits) is reserved.

0x0001(the low 16bits) is number of channels/axes (i.e. 1 channel, valid index is 0)

4[0x00000004]: options for reading

260[0x00000104]: options for writing

Byte	Value	Description of options
0	04	Syntax: (please see Parameters for writing in the table above) 0x00 = Char 0x01 = Unsigned int32 0x02 = Float 0x04 = String please see nF_common.h for detail
1	00	Command level: 0 = Normal 1 = Advanced Others = reserved
2	00	Reserved
3	00	Reserved

Example to read the current active parameter (from RAM),

? 0x6001 0 0x21000004

Example to write to flash

0x6002 0 0x21000004 '0000'

Example to store all parameters to flash:

0x6003 100

4.4. Operation

4.4.1. Position Commanding and Reading

The controller is ready in about 2 seconds after powered-on. The default state is Servo-Off and 0V output.

In order to move the stage to a desired position: (e.g. axis to position 1.0)

- 1) Set Servo-On

Command-ID: 0x2040

1st Parameter: axis index = 0 (index from 0, for 1st axis it should be 0, 2nd be 1, and so on)

2nd Parameter: value = 1 (1=Servo-On, 0=Servo-Off)

For simplification, it is listed as: 0x2040 0 1


- 2) Set target to 1.0:

0x2002 0 1.0

- 3) Check position:

?0x2001 0 (command with read-back flag)

4.4.2. Function block diagram



Note: The sensor has one [low-pass-filter](#). The controlling voltage has 2 [notch-filters](#).
Set fc to 0.0 to disable filter function.

4.4.3. Target selection

As shown in the figure, targets can be selected from different sources for each axis.

For closed loop (Servo-On): The target is a position value.


For open-loop (Servo-Off): The target is a voltage value.

Target sources include command and analog input. At start-up, the target is default to 'command'. (ID: 0x2002/0x2003 for closed-loop; 0x2004/0x2005 for open-loop).

For example, to connect the axis target to Ain-value:


0x2041 0 2 (2 stands for Ain-Value0)

Note: use **"?0xFFF9 0x2041"** to see valid settings




4.4.4. Trajectory controlling

The selected target will be passed to the trajectory module, which calculates the effective value used as target (target used) according to the maximum velocity and acceleration parameters.



The relation between target_used and velocity / acceleration is shown below.



Example for using the trajectory module for the 1st axis

Set max-acceleration to e.g. 10um/(s*s). Optional, since parameter can be saved in flash.

```
0x6001 0 0x20400001 10.0
```

Set max-velocity to 1um/s. Optional, since parameter can be saved in flash.

```
0x6001 0 0x20400002 1.0 or with command
```

```
0x2050 0 1.0
```

Enable trajectory controlling. Optional, since parameter can be saved in flash.

```
0x6001 0 0x20400000 1 or with command
```

```
0x2042 0 1
```

Note:

for scanning applications, trajectory controlling should be disabled.

```
0x6001 <axis-ID> 0x20400000 0 or 0x2042 <axis-ID> 0
```


4.4.5. Analog I/O

Analog input can be used for target signals so that no software controlling is necessary (a default macro is required for configuration). Analog input has an internal 1kHz low pass filter.

Table 5.4.5 : Description of analog inputs


Controller	Number of inputs	Index
EBD-060310 / EOD-060310/ EBD-060310 / EOD-060310	1	0
EBD-060320	2	0, 1
EBD-060330	3	0, 1, 2

Calculating method:



Analog-Output:

The analog output can be used as a monitor-signal.



Note (a): valid only for controller EBD-0603**

Note (b): please use “?0xFFF9 0x21FE” to see all valid options

Option <3> for the EBD-0603** controller:

Output-range: -5V ~ +10V

$$\text{Output-Voltage} = \text{Position} * \text{Gain} + \text{Offset}$$

For example of axis0:

Position: 0~25um

Output voltage: -5.0 ~ 5.0V

⇒ Gain = 0.4, Offset = -5.0

Command (or with Parameter-GUI):

0x6001 0 0x21400410 -5.0 0 0x21400411 0.4

4.4.6. Event

Event is used for triggering data-recorders and/or motion (synchronizing the operation). One event signals (index 0) is available. To use an event, it should be first configured and then connected to data-recorders.


Event is set from different resources, such as internal status or digital-input.

Example: Event0 to the digital input.


0xD040 0 30 1 (30: digital in)
 0xD041 0 1 (1: enable)

Note: use “?0xFFF9 0xD040” to see valid settings

Note: Digital input is only valid in EBD-060310/EBD-060310. Signal detection/delay timing is 20us.



4.4.7. Data-Recorder



There are 2 data recorders to store data synchronously in memory which can then be read-back by software. The memory size of each recorder is 512 DW (double-word).

To use data recorders:

- 1) select data sources for recorder with command 0x4050. Command parameters are:
 <recorder-index> <source-ID> <source-channel>
 For example: To select recorder 0 with axis position, and recorder 1 with analog input
 0x4050 0 1 0 1 12 0
 Note: use “?0xFFF9 0x4050” to see valid settings
- 2) enable recorder.
 0x4040 0 1
- 3) enable and set event.
 0xd041 0 1 (enable event)
 0xd042 0 1 (set event)
 Now data will be saved at each servo-loop (for rate = 1).

- 4) check recorded data length.
 ?0x4042 0 (Read-back command)
 In case of 50k servo-loop and rate=50, to fill up 512 data-buffer, it takes 512ms.

- 5) when finished, read data.
 ?0x4011 0 0 512 (read 512 data out of table 0, from position 0)
 ?0x4011 1 0 512 (read 512 data out of table 1, from position 0)

Example 2: recorder PID-Target and position triggered by command:


0xd041 0 0	(Disable event)
0x4040 0 0	(Disable recorder)
0x4050 0 7 0 1 1 0	(Config recorder source)
0x4040 0 1	(Enable recorder)
0xd041 0 1	(Enable event)
0xd040 0 40 0	(Event option: triggered by next command)
0x2003 0 0.1	(Relative move and start-recorder)
?0x4042	
?0x4011 0 0 512	

4.4.8. Firmware update

Power on the controller and start software: nFUpdater.exe

Note: the current controller can't use the Ethernet interface for firmware update.

1. Select the right COM-port



2. Load the firmware and then “Start”

After a successful execution, controller will be restarted, and the new firmware will be working.

Note: after update, please check parameters with nFControl.exe and save them with “0x6003 100” (since the updated firmware may have new parameters, which confirms controller’s states and then be active).

4.4.9. Macro function

In case that the controller must be used without interface/software, the initialization should be performed automatically with saved commands. This comes to the macro function.

Table 5.4.12 Command for Macro function

Command ID	Syntax (read/write)	Function description	Comment
0xE000	-/ <string: name> write only	Start recording a new macro	The old macro will be replaced when a same name is given. Only saves command from one interface.
0xE002	-/ <none> write only	End of recording	
0xE003	<none> / - read only	List all macros	
0xE004	-/ <string> read only	Show contents of macros	Command package in binary format
0xE005	<none> / <string>	Set/get default macro	Controller starts default macro each time it re-started
0xE006	-/ <string> write only	Delete macro	
0xE010	<none> / <string>[<times>]	Start macro / get running status	<times> is optional, 1 when not set.
0xE011	-/ <none> Write only	Stop running macro	
0xE012	-/ <ms> Write only	Delay millisecond	Only used in macro function

Note: Name is case sensitive, maximal 8 chars.

Example 1: define a macro which turns servo-on


```

0xE000 sServoOn    --- macro name is 'ServoOn'
                   --- 's' is only for software which means parameter is a string
                   --- or just 0xE000 'ServoOn'

0x2040 0 1        --- servo on
0xE002            --- end of recording macro


?0xE003           --- show all macros
?0xE004 'ServoOn' --- show all commands in macro

0xE010 'ServoOn'  --- start macro : just to test
  
```



Example 2: enable analog controlling

0xE000 'init'	--- macro name is 'init'
0xFFFF 1	--- Command level to 1
0x2041 0 2	--- select the 1 st analog input as target of axis1
0xE010 'ServoOn'	--- run macro, or just "0x2040 0 1"
0xE002	--- end of recording macro
?0xE003	--- show all macros
0xE010 'init'	--- start macro : just to test
0xE005 'init'	--- set as default macro



0xE005

--- without macro name, the default macro will be disabled

Example 3: Step movement

Move from 0 to 10um in step of 0.1, and then back to 0 in step of 0.2um

```
0xE000 'stepUp'      --- macro for step-up
0x2003 0 0.1        --- move axis0 relative (0.1um)
0xE012 10          --- Delay 10ms
0xE002            --- end of recording macro
```

```
0xE000 'stepDown'   --- macro for step-down
0x2003 0 -0.2       --- move axis0 relative (0.2um)
0xE012 10          --- Delay 10ms
0xE002            --- end of recording macro
```

```
0xE000 'Main'       --- top-level macro
0x2040 0 1          --- axis0 servo ON
0x2002 0 0.0        --- move to position 0.0
0xE012 10          --- Delay 10ms
0xE010 'stepUp' 100 --- step up 100 times
0xE012 10          --- Delay 10ms
0xE010 'stepDown' 50 --- step down 50 times
0xE002
```

Run the macro:


```
0xE010 'Main'
```

Note:

- Macro name is a string, please pay attention for the special character ''
- Macro name is case sensitive.

4.4.10. Auto-zero function

Zero-positions may be shifted by load, transport or mounting. This can lead to mechanics not being able to reach their limits (overflow-indication as shown below).



In case of strain-gauge sensors, the offset can be shifted to another voltage with command 0x2150.

Step 1: Turn all Servo-mode to OFF

Step 2: Set voltage to example -20V

This means that the sensor value should be about 0.0 at -20V, depending on how much voltage is reserved for other compensations. For example:

Set to -20V, when -20V ~ 150V corresponding to whole stage range or

Set to -30V, when -30V ~ 165V => whole stage range.

Step 3: Send the auto-zero-command

0x2150 0 5.0

Command ID: 0x2150

Syntax: <command-ID> <sensor-channel-index> <voltage-step>

Note: this can last for some seconds.


Step 4: Verify the stage can move the whole range:

Turn Servo-ON, and check the limit position.

Step 5: When OK, save the new parameters to controller and stage

0x6003 100 (Save parameters to controller)

0xD000 (Save parameters to IDChip of the stage)




5. Explanation: Open- and Closed-Loop

5.1. Open Loop Behavior

Open loop operation means that simply voltages are applied to a PZT actuators, which then perform expansion or contraction. The latter is depending on which coupling constant is relevant and in which direction the voltages are applied.


Typical behaviour of a d_{33} PZT-actuator at an electrical field of ± 3 KV/mm (counter-polarization occurs at the low turning points):




The symmetry of this butterfly-curve for plus and minus voltages and losses at repolarization lead to only unipolar usage making sense. Contraction at counter-fields can be added to 20%-30% of the nominal voltages. Maximum voltages and maximum counter-voltages depend on the kind of actuator. Follow manufacturer specifications!

nanoFaktur controllers in standard-configuration amplify by a factor of 15. The offset is at 0 V. A voltage of 0 to +10 V at the input-BNC will drive the output from 0 to +150 V. An extended output-range of about -45 to +180 V is serving as a reserve for closed-loop operation only.

5.2. Voltage-Behavior of a d₃₃- PZT




The curve above shows the typical behaviour of a nanoFaktur MPO-050050 PZT-multilayer stack. The stack was driven at voltages from 0 to 160 V, expansion monitored with a probe. When a PZT actuator is reactivated after a long rest, it performs a virgin curve. The Y-axis departure of the virgin-curve depends on the time of the rest. The existence of a gap between the zero-points of the virgin-curve and the later curve is indicating the phenomenon drift. A drift does always exist after the PZT has been used. The drift has a magnitude of 1% per time-decade.



5.3. Closed Loop Operation

Most applications require precise positioning and/or stable resting at positions. Hysteresis and drift described above shall be overcome. This can be achieved by using a linear position sensor measuring what the piezo-actuator is doing. A controller can compare the commanded position (input) with the actual position and generate a corrected voltage for the piezo. This is optimally done repeatedly (in loops). The frequency (band-width) of the loop is decisive for the dynamics of closed-loop operation. The inverse value of the band-width is the control-loop time. This is as low as 50 μ s for 2nd generation EBD-controllers.



6. Troubleshooting

Please first update firmware to the newest stand.

Problem	Reason	Solution
USB connection		Install the dedicated driver
TCP/IP connection: no interface found	IP address not configured	Enable DHCP when used in a sub-net (First configure controller via another interface, and then save parameters in flash)
TCP/IP connection: already connected	TCP/IP allows only one connection	Software should disconnect the interface when closed
status LED red	Stage connector not connected Unknown stage type System temperature problem Controller is busy	Read stage status with “? 0x204F” To reset status: “ 0x204F” Information: “?0xFFF9 0x204F”
Channel LED status	Off: Open loop Blinking: Stage is Moving Green: On-target	
Channel LED yellow	Overflow: Target can't reach and the voltage is at the limit.	Check soft-limit Run auto-zero function
No movement	Voltage limit reached Position limit reached Small velocity value and Trajectory enabled Target selection	Check open-loop soft-limit Check close-loop soft-limit Disable trajectory controlling Check “?0x2041”
Monitor output		Check the pin-definition
Oscillation	Notch-filter setting	Disable the filter